

The LOXX® TBR-Plate = Turn button replacement!



1. You have bulky turn buttons and would like to replace them with the smart LOXX® fastening system? Clever!



2. You order the new Original LOXX® TBR-Plate and also the well-established original LOXX® upper parts (long washer). Easy!



3. You replace the old turn button with the new original LOXX® TBR-Plate. The center hole distance is exactly equal. Thought out!



4. You screw the original LOXX® upper part (long washer) into the already existing eyelet of the turn button. It fits perfectly into the opening. Brilliant!





It's so easy!
It's fantastic!

